



## CARE & CLEANING GUIDELINES





**MPWORKING GLASSES** 

# ONYOUR LAMPWORKING GLASSES

We know how vital your lampworking glasses are, so we made these simple guidelines to best clean, store, and wear your glasses.

Keeping lampworking glasses clean and scratch free not only keeps you seeing clearly, but it extends the life of the product as well. The number one reason for scratched lenses is improper lens cleaning and the second is improper storage.

Lampworking glasses should be cleaned and storaged with extra care in order to prevent any kind of damage to its lenses.

## **UNCOATED LENSES**

Clean with anti-bacterial detergent or hand soap with no microbeads or grit added.

Gently rub lenses in straight lines under clear running water.

Dry with soft, lint-free cloth.

You can also use alcohol based lens wipes.

## FOGFREE LENSES

DO NOT USE ALCOHOL.

It will degrade the anti-fog coating.

Clean with anti-bacterial detergent or hand soap with no microbeads or grit added.

You can also use non-alcohol based lens wipes.

Use a light pressure in straight lines, thorougly cleaning all surfaces of lenses and frame.

Dry with microfiber cleaning cloth.

NOTE: Washing anti-fog coated lenses will degrade the coating after several washings.

IT IS RECOMMENDED TO REJUVENATE THE
ANTI-FOG COATING WITH A PRODUCT LIKE OUR
RX SAFETY DRY ANTI-FOG CLOTH

## MIRROR COATED & ANTI-REFLECTIVE LENSES

DO NOT USE ALCOHOL.

It will degrade the mirror & anti-reflective coating.

Clean with anti-bacterial detergent or hand soap with no microbeads or grit added.

Gently rub lenses in straight lines under clear running water.

Dry with soft, lint-free cloth.

**DO NOT AUTO-CLAVE.** 

NEVER USE AMMONIA OR CHLORINE BASED CLEANERS.

DO NOT USE CIRCULAR MOTIONS WHILE CLEANING, AS IT CAN DAMAGE APPLIED COATINGS.

Place your lampworking glasses inside the case every time you take them off.

Always place your lampworking glasses inside the case with the lenses facing upward.

Do not set your lampworking glasses close to the sinks and vanities.

They can get splashed with corrosive substances in these areas.

Do not put your lampworking glasses into a bag of any kind without the hard case.

The contents of the bag can easily scratch your lenses.

# ALWAYS USE YOUR HARD CASE

Avoid putting your lampworking glasses on top of your head.

The top of the head is generally wider than the face and can

Don't push on the nose piece.

This motion can distort the nose piece; try to adjust the nosepiece before placing it on your face.

Use both hands to remove your lampworking glasses.

This motion will keep your frames' alignment and minimize changes over time.

If you need to remove your glasses constantly, make sure to use your retainer cord.

Only lampworking glasses designated as fitover model can be used over prescription glasses.

# CAUTION!

**DO NOT** use clothing, paper towels, napkins or facial tissue to clean your lenses. Most of these fabrics contain abrasive fibers and/or debris, which can easily scratch the lens and affect the level of vision.

**DO NOT** use household cleaning products to clean your lenses. Cleaning products usually contain harsh ammonia-based chemicals that can destroy the protective coating on your lenses.

**DO NOT** wash your microfiber cloth with your regular laundry. The detergent and dryer sheet could leave oils on the cloth. Just wash it in the sink with lotion free, non-abrasive liquid dish soap and air dry.

**DO NOT** place your glasses lens side down on a surface. This will scratch the lenses.

FOLLOW THIS GUIDELINES AND EXTEND THE LIFETIME OF YOUR LAMPWORKING GLASSES.